

A. Purpose

To cure the epoxy perimeter of the assembled LCD using the hot pressed oven..

B. Equipment set-up

Air bladder type hot pressed oven.

C. Process

1. Place the assembled LCD in the centre of air bladder of the fixture for curing.
2. Close the oven door.
3. Turn on the power of the oven.
4. Set the overheat temp alarm at 200 deg C
5. Press the RESET button.
6. Press the RUN key in the controller after selecting the program 1
7. Take out the curing LCD after about 2 hours.

